



SKP-S Series (PIANO Type)





Model	SKP-02S	SKP-04S	SKP-06S	SKP-08S	SKP-10S
Pole	2	4	6	8	10
L(mm)	6.48	11.56	16.64	21.72	26.80

BSD Series (Box Type)





Model	BSD-101	BSD-102	BSD-103	BSD-104	BSD-105	BSD-106	BSD-107	BSD-108	BSD-109	BSD-1010
Pole	1	2	3	4	5	6	7	8	9	10
L(mm)	3.2	5.0	8.2	10.1	13.3	15.2	18.4	20.2	22.8	25.3

DS Series





Pole	DS-02	DS-03	DS-04	DS-05	DS-06	DS-07	DS-08	DS-09	DS-10	DS-12
L(mm)	6.64	9.18	11.72	14.2	16.8	19.34	21.88	24.42	26.96	32.04

DA Series (PIANO Type)



Pole	DA-02	DA-03	DA-04	DA-05	DA-06	DA-07	DA-08	DA-09	DA-10	DA-12
L(mm)	6.64	9.18	11.72	14.2	16.8	19.34	21.88	24.42	26.96	32.04

DP Series (PIANO Type)



Pole	DP-02	DP-03	DP-04	DP-05	DP-06	DP-07	DP-08	DP-09	DP-10	DP-12
L(mm)	6.64	9.18	11.72	14.2	16.8	19.34	21.88	24.42	26.96	32.04